


READ THIS FIRST!! FOLLOW STEPS OF YOUR MAIN INSTRUCTION SHEET, ASSEMBLIES 1 THRU 8 ONLY, NOW PROCEED WITH THESE EASY-TO-FOLLOW INSTRUC-TIONS FOR MOTORIZING YOUR ALLISON ENGINE.






Cement 26 onto 27, locating-as shown in Small Drawing 2. Lubricate at all points shown and set aside to dry.




## LUBRICATE AT ALL POINTS SHOWN

Place, DO NOT CEMENT 4M into part 28. Cement Assembly 9M-B into place in part 28. Be sure large gear on Assembly 9M-B engages into small gear on part 4M.



LUBRICATE AT ALL POINTS SHOWN Place, DO NOT CEMENT 1M into 2M. Place a drop of cement on pin 3M. Press pin on 3M into 1M.



## LUBRICATE AT ALL POINTS SHOWN

Place, DO NOT CEMENT, part 29 into Assembly 9M-C. Be sure small ge engages into inner gear on part 29, as shown. DO NOT SET THIS AST Proceed to Assembly 9 of Main instruction Sheet. Turn part 27 slowly, see that all gears are engaging properly. NOTE: DISCARD part 39 Assembly 12, because your Motor will replace this part. CONTINE ASSEMBLIES 10 THRU 37.